

AIR KING EQUIPMENT
For Use with TS SOLIDBAR

UNIT*	EQUIPMENT	COVERAGE AREA	DIMENSIONS & MOUNTING
A AirKing 1 Or 1A with 3 Prong Plug	Electrical unit for use in two patient rooms or a bathroom. Features and attractive vandal deterrent type cover. Holds 1 – 4 bars.	940f ² , 7520 f ²	9 ¼" x 4 ½" x 4 ¼" Use 2 screws for permanent installation a 1 for portable use.
B AirKing 2	Battery operated unit. Holds 1 SOLIDBAR or 4 MINIBARS. Requires 1 "D" cell battery.	425 f ² , 3400 f ²	9" x 4" x 3 ½" Use 2 screws or self-stick tape.
C AirKing 3	Passive unit. Holds up to 4 TS SOLIDBARS (usually 1 required). White, brown or gray cabinet.	250f ² , 2000f ²	9" x 4" x 3 ½" Use 2 screws or self-stick tape.
D AirKing 4	Battery operated unit. Requires 1 "D" cell battery. Features and attractive vandal deterrent type cover. Holds 1 – 4 bars.	875f ² , 7000f ²	9 ¼" x 4 ½" x 4 ¼" Use 2 screws for permanent installation a 1 for portable use.
E AirKing 5	Electrical unit for permanent installation or portable use. Holds 2- 10 TS SOLIDBARS (use 2 bars for a two patient room and 6 or 7 for a ward area). Reusable filter. Black case with handle.	7500f ² , 60000f ²	11" x 15" x 4 ½" Mount with screws or use as a portable unit. <i>This unit is UL listed.</i>
F AirKing 12	For use with air handling systems. Installed on the suction side, the system pulls air through the unit. Normally requires 8 – 12 bars.	3 – 14 tons	11" x 15" x 4 ½" Screw to duct or use flex hose for remote mounting.
G AirKing 36	Installed with a flexible telescoping hose and two connectors. If any air leaks are detected, cover with duct tape. This unit requires 28 – 36 bars.	15-75 tons	11" x 15" x 4 ½" Screw to duct or use flex hose for remote mounting.
H AirKing Mini-Cabinet	Unit for use with 1 TS MINIBAR. May also be used with ½ of a regular TS SOLIDBAR. White cabinet.	125f ² , 1000f ²	5" x 2 ½" x 2 ¼" Uses self-stick tape.
I AirKing Easy-Mount	Cardboard unit holds 1 TS SOLIDBAR or 1 TS MINIBAR. Effective in areas prone to vandalism.	125f ² , 1000f ²	3 ¾" x 3 ½" x ¾" Uses self-stick tape.

* Letters refer to AirKing equipment pictured on the colored sales sheet.

CLEANING OR ALL MACHINES: Use a mild detergent solution and soft cloth to wipe both the inside and outside of the unit. Quat disinfectant may be used where appropriate. Filters (if unit has one) should be brushed off and disinfectant if appropriate.